

USING WITH NOKIA 8910i

a. ACTIVATING THE BLUETOOTH

You must activate your Bluetooth to establish a Bluetooth connection between your mobile phone and other Bluetooth devices.

1. Press **Menu** ► **Connectivity** ► **Bluetooth**.
2. Press **Select** and choose **On**.
3. Continue pressing **Back/Exit** key to get out of Menu.

QUICK ACCESS:

Press **Menu** followed by the sequence of numbers below.

	Connectivity	Blue tooth	Select	On	Select
8910i	10	1	1	1	1

b. PAIRING TO THE CELLULAR PHONE

Pairing will create a link or connection between your two Bluetooth devices, the Headset and your phone.

1. Bring the cellular phone at about 20 cm from the Headset.
2. Detach the Headset from the holster/base.
3. Ensure that the Headset is turned off (see *B.Turning On/Off the Headset*).
4. From the OFF state, press the multi-function button for 10 seconds until you hear a distinctive three-tone sound and the Bluetooth indicator LED changes from blinking blue to alternate blinking of red and blue. This indicates that the unit is now ready for pairing.
5. Press **Menu** ► **Connectivity** ► **Blue tooth**.
6. Scroll to **Search for audio accessories** and press **Select**. The phone will then search for other Bluetooth devices. **Select** the name of this Headset. The phone will initiate connection with the Headset.

QUICK ACCESS (for step 5):

Press **Menu** followed by the sequence of numbers below.

	Connectivity	Blue tooth	Search for audio accessories
8910i	10	1	2

7. Enter "0000" as the passcode then press **Ok**.
8. Continue pressing **Back/Exit** key to get out of Menu.

The Headset is paired and ready to use.

Keypad tones can be heard on the Headset every time the keypad is pressed.

c. AUTO ACCEPT MODE

The auto accept mode allows the Bluetooth function to be turned on automatically whenever the user receives or make a call via the Bluetooth Headset.

1. Press **Menu** ► **Connectivity** ► **Bluetooth**. Scroll down to **View paired devices**.
2. Select the Headset and press **Options**. Scroll to **Request conn. authorisation** and press **Select**. Choose **No** and press **Select**.
3. Continue pressing **Back/Exit** key to get out of Menu.

QUICK ACCESS:

Press **Menu** followed by the sequence of numbers below.

	Connectivity	Blue tooth	View paired devices	Select
8910i	10	1	4	Options

d. ANSWERING/RECEIVING A CALL

When the phone is receiving a call, ring tone will be heard on the Headset and on the phone.


1. Press down the multi-function button once to answer the call.
2. End the call by pressing the button again.

Note: Cell phone buttons can also be used to answer a call but audio will still be heard on the Headset.

e. **MAKING A CALL with the Headset on**



Normal dialing

1. Key in the phone number and press  key. As you dial, keypad tones can be heard on the Headset.
2. Press the multi-function button to hang-up and terminate the call.



Voice dialing

Refer to step i for the procedure when recording for voice dialing.

1. Press the multi-function button once to activate voice dialing.
2. A beep will then be heard on the Headset prompting the user to say the voice name/voice tag of the person to call.
3. Say the voice name. The voice will be played back to you. The phone will then place the call automatically. In case the cellular phone does not recognize the name spoken, the steps above may be repeated.



Redialing

Press twice quickly the multi-function button to redial the last number.

f. **AUDIO TRANSFER**

Audio Transfer can be done by pressing the multi-function button **2times quickly** (when Headset to phone); pressing the multi-function **once** (when phone to Headset). It can also be done using the cellphone; access the phone's call options during an ongoing call.

g. **REJECTING A CALL**

Press twice quickly the multi-function button to reject an incoming call.

h. **SETTING THE VOLUME**

The Headset has a digital volume control which can be accessed through the *multi-function button*. Volume setting can be done during calls only.

1. Switch the multi-function button sideways in a clockwise direction to increase the volume.
2. Switch it counterclockwise to decrease the volume.
Note: As you press the button, the volume level is simultaneously displayed on the cellular phone.
3. Continuous sideward switching of the multi-function button (*clockwise or counterclockwise*) can rapidly increase or decrease the volume. *If the volume set is too high, it can cause feedback (whistling sound), echo or background noise during calls on some cell phones.*

i. **RECORDING FOR VOICE DIALING**

Use your phone when recording voice dialing.

1. From standby mode, scroll arrow up or down.
2. Find a contact to which you want to make a voice dial. Press **Details** ► **Options** ► **Add voice tag**. Follow the instructions. "Voice tag saved" will be displayed if recording is successful.
3. In case you wish to change your recorded voice, press **Names** ► **Voice tags**. Scroll to the name to which you want to change the voice tag then press **Options** ► **Change**. Follow the instructions.
4. Continue pressing **Back/Exit** key to get out of Menu.

Note: Noisy environment could affect voice recognition. Record voice in a quiet environment.