


USING WITH PANASONIC X70

a. ACTIVATING THE BLUETOOTH

You must activate your Bluetooth to establish a Bluetooth connection between your mobile phone and other Bluetooth devices.

1. Go to Menu by pressing the center button of the 5-way navigation key featured as .
2. Scroll to *Organizer*, **Select**. Scroll to *Connect*, **Select**. *Bluetooth*, **Select**.
3. *On/Off*, **Select**. Choose *On*, **Select**.

QUICK ACCESS:


Press *Menu* followed by the sequence of numbers below.

	Organizer	Connect	Bluetooth	On
X70	8	9	1	Select

4. Continue pressing  to exit.

b. PAIRING TO THE CELLULAR PHONE

Pairing will create a link or connection between your two Bluetooth devices, the Headset and your phone.


1. Bring the cellular phone at about 20 cm from the Headset.
2. Detach the Headset from the holster/base.
3. Ensure that the Headset is turned off (see *B. Turning On/Off the Headset*).
4. From the OFF state, press the multi-function button for 10seconds until you hear a distinctive three-tone sound and the Bluetooth indicator LED changes from blinking blue to alternately blinking red and blue. This indicates that the headset is now ready for pairing.
5. Go to *Menu* by pressing center button of  key. Scroll to *Organizer*, **Select**. Scroll to *Connect*, **Select**. *Bluetooth*, **Select**.
6. Choose *Discover & Pair*, **Select**.

QUICK ACCESS (for step 5&6):

Press *Menu* followed by the sequence of numbers below.

	Organizer	Connect	Blue tooth	Discover & Pair
X70	8	9	1	2

The phone is now searching for pairable devices to be added.

7. Select the device you want to pair with your cell phone, then press **Pair**.
8. Enter "0000" as the passkey then press **Ok**. If the pairing is successful, the alternating red/blue lights will stop.
9. Continue pressing  to exit.

The unit is now ready to link calls from the phone directly to the Headset. An icon appears during the standby mode indicating that the Headset is linked with the phone. If pairing is unsuccessful, the steps above may be repeated.

c. ANSWERING/RECEIVING A CALL

When the phone is receiving a call, two dissimilar ring tones will be heard on the phone and on the Headset.

1. When answering is done on the Headset (*that is, pressing the multi-function button once*), the audio will be heard from it.
2. When answering is done on the phone, audio will be heard on the phone (*not on the Headset*). But if you wish to hear and transfer the call to the Headset, just press once on the Headset's multi-function button.

3. To terminate the call, press the multi-function button once.

d. **MAKING A CALL with the Headset on**



Normal dialing

1. Using your phone, enter the contact number and press **SEND** key. Audio is heard on the phone and no immediate audio heard on the Headset yet. You have to press once on the multi-function button to transfer the audio to the Headset.
2. To terminate the call, press down the multifunction button once.



Voice dialing

Refer to step h and i for the procedure when activating and recording for voice dialing.

1. Press the multi-function button once to activate the voice dialing.
2. *Beep* will then be heard on the Headset prompting the user to say the name of the person to call.
3. Say the name. The name will be played back to you. The phone will then place the call automatically. In case the cell phone does not recognize the name spoken, the steps above may be repeated.
4. To terminate the call, press down the multifunction button once.



Redialing

Press the multi-function button twice quickly to redial the last number.

e. **AUDIO TRANSFER**

Audio Transfer can be done by pressing down the multi-function button once or accessing the cell phone's Menu during ongoing calls.

f. **REJECTING A CALL**

Press the multi-function button twice quickly to reject an incoming call.

g. **SETTING THE VOLUME**

The Headset has a digital volume control which can be accessed through the *multi-function button*. Volume setting can be done during calls only.

1. Switch the multi-function button sideways in a clockwise direction to increase the volume.
2. Switch it counterclockwise to decrease the volume.
3. Continuous sideward switching of the multi-function button (*clockwise or counterclockwise*) can rapidly increase or decrease the volume. *If the volume set is too high, it can cause feedback (whistling sound), echo or background noise during calls on some cell phones.*

Note: It is also possible to use the volume keys of the cellular phone to set the volume.



h. **ACTIVATING THE VOICE DIALING**

Use your phone when recording for voice dialing. Before voice dialing, you must first turn on the *Voice Dial* function and record your voice. To turn voice dial on:

1. Go to Menu by pressing key. Scroll to *Contacts List*, **Select**.
2. On the *Contacts List*, choose *Settings*, **Select**.
3. Choose *Voice Dial*, **Select**. Choose *On* and press **Ok**.
4. Continue pressing to exit.

i. **RECORDING FOR VOICE DIALING**

1. Go to Menu by pressing key. Scroll to *Contacts List*, **Select**.
2. On the *Contacts List*, scroll down to *Voice Dial*, **Select**.
3. Press *Menu*. Choose *Add*, **Select**.

4. On the contact names listed, choose the one you want to make a voice dial.
5. After choosing a contact, press again center button of  key. Choose *Recall*, **Select**. A statement "*Please Record Your Voice!*" appears. Press **Ok**.
6. Follow the instructions on screen. Voice is then saved on the phone. Under Voice Dial list, the name which already has a voice command appears.
7. Continue pressing  to exit.

Note: Noisy environment may affect voice recognition. Record your voice in a quiet environment.