


## USING WITH SONY ERICSSON P800 / P900



### a. ACTIVATING THE BLUETOOTH

You must activate your Bluetooth to establish a Bluetooth connection between your mobile phone and other Bluetooth devices.

1. Flip open mode. On the phone's **Applications** window, scroll to **Control Panel** and tap it using the "stylus". On the lower portion, tap **Connections** index. Tap **Bluetooth**. Tap **Settings** index. On the **Operation mode**, tap **On**.
2. Tap  to exit and return to the Applications window.

### b. PAIRING TO THE CELLULAR PHONE

Pairing will create a link or connection between your two Bluetooth devices, the Headset and your phone.

1. Bring the cellular phone at about 20 cm from the Headset.
2. Detach the Headset from the holster/base.
3. Ensure that the Headset is turned off (see *B. Turning On/Off the Headset*).
4. From the OFF state, press the multi-function button for 10 seconds until you hear a distinctive three-tone sound and the Bluetooth indicator LED changes from blinking blue to alternately blinking red and blue. This indicates that the unit is now ready for pairing.
5. **Press the multi-function button once again for a short time, to access Headset Pairing Mode.**
6. Flip open mode. On the phone's **Applications** window, scroll to **Control Panel** and tap it. On the lower portion, tap **Connections** index. Tap **Bluetooth**. Tap **Devices** index. **Bluetooth devices** is displayed as sub-title. Tap **Add**. The phone is now searching for pairable devices.
7. Devices found are then displayed. Tap the device you want to pair with your phone. **Bonding in progress** will be displayed on screen and simultaneously, the phone will ask for the pass key.
8. On the lower left corner of the screen, tap . Enter "0000" as the passkey then tap **Done**. Also tap **Done** under the sub-title, "Secure Connection." If pairing is successful, the alternating red/blue lights will stop.
9. Tap  to exit and return to the **Applications** window. If the pairing is unsuccessful, the steps above may be repeated.

The unit is now ready to link calls from the phone directly to the Headset. An icon will appear during the standby mode indicating that the Headset is linked with the phone.

### c. ANSWERING/RECEIVING A CALL

When the phone is receiving a call, a ring tone will be heard on the Headset.

1. Just press the multi-function button down once to answer the call. Pressing the button again will hang-up and terminate the call.
2. If you wish to answer a call on the cellular phone, just press **YES** and the call will automatically be transferred to the phone. Pressing the multi-function button will transfer the call to the Headset.
3. To terminate the call, press the multi-function button again.

### d. MAKING A CALL with the Headset on



#### **Normal dialing**

1. Enter the contact number and press **OK**. Audio can be heard on the Headset.
2. Press the multi-function button to hang-up and terminate the call.

## **Voice dialing**

Refer to step g and h for the procedure when activating and recording for voice dialing.

1. Press the multi-function button once to activate the voice dialing. Audio will be heard on the Headset.
2. A beep will then be heard on the Headset prompting the user to say the name of the person to call.
3. Say the name. The name will be played back to you. The phone will then place the call automatically. In case the cell phone does not recognize the name spoken, the steps above may be repeated.
4. Press the button again to terminate the call.

### **e. AUDIO TRANSFER**

Audio Transfer can be done by pressing the multi-function button or accessing the cell phone's menu during ongoing calls.

### **f. SETTING THE VOLUME**


The Headset has a digital volume control which can be accessed through the *multi-function button*. Volume setting can be done during calls only.

1. Switch the multi-function button sideways in a clockwise direction to increase the volume.
2. Switch it counterclockwise to decrease the volume.
3. Continuous sideward switching of the multi-function button (*clockwise or counterclockwise*) can rapidly increase or decrease the volume.

Note: *If the volume set is too high, it can cause feedback (whistling sound), echo or background noise during calls on some cell phones.*




### **g. ACTIVATING THE VOICE DIALING**

Use your phone when recording for the voice dialing. Before voice dialing, you must first turn on the name dialing function and record your voice. To turn voice dialing on:

1. Flip open mode. On the phone's **Applications** window, tap *Phone*.
2. Tap *Edit* then tap *Preferences*. A list of features will appear.
3. Tap *Voice Control* then tap the box aligned to *Voice dialing* to check and activate the voice dialing feature. Tap the box aligned to *Play caller name* so that the name will be played back to you.
4. Tap **Done** on the on screen button when finished.
5. On the Preferences mode, tap **Done** again.
6. Tap  to exit and return to the Applications mode.

### **h. RECORDING FOR VOICE DIALING**

The voice dialing feature is only applicable to contacts saved to phone memory.

1. Flip open mode. On the phone's **Applications** window, tap *Contacts*.
2. Tap the contact where you want to add a voice dialing feature. Tap **Edit**. Scroll to **Edit Contact**. Tap  on the on-screen buttons.
3. Tap **Record**. *Speak after tone* will be displayed on the screen.
4. Record your voice. To check if your recording is of good quality, tap **Play**. If not, tap **Record** again. Press **Done** when finished.
5. Tap  to make another record and repeat the steps above. To return to the Applications window, tap  button.

Note: Noisy environment may affect voice recognition. Record your voice in a quiet environment.