



USING WITH I-mate Pocket PC

a. ACTIVATING THE BLUETOOTH

You must activate your Bluetooth to establish a Bluetooth connection between your Pocket PC Phone and other Bluetooth devices.

1. Tap . Scroll down to *Settings*. Tap *Connections* tab. Tap *Bluetooth*.
2. Select *On* and tap **ok**.
3. Tap **V** to exit.

b. PAIRING TO THE CELLULAR PHONE

1. Bring your PC phone at about 20 cm from the Headset.
2. Detach the Headset from the holster/base.
3. Turn off the Headset.
4. From the OFF state, press the multi-function button for 10seconds until you hear a distinctive three-tone sound and the Bluetooth indicator LED changes from blinking blue to alternately blinking red and blue. This indicates that the headset is now ready for pairing.
5. **Press the multi-function button once again for a short time, to access headset pairing mode.**
6. Tap . Scroll down to *Settings*. Tap *Connections* tab. Tap *Bluetooth*.
7. Tap *Bonded Devices* tab. Tap *New*.
Your device now searches for Bluetooth devices and displays them in the list.
8. Tap the name of the device that you want to bond with your PC phone, and then tap *Next*.
9. Enter "0000" as the Device PIN and then tap *Next*.
10. Tap *Finish*. (Note: In *Name*, you may or may not edit the name of your bonded device).
11. For the question, "This Bluetooth device supports headset profile, would you like to set it as your Blue tooth headset?", tap *Yes* tab.
12. Tap **ok**, and then **V** to exit.

The unit is now ready to link calls from the PC phone directly to the Headset. An icon appears during the standby mode indicating that the Headset is linked with the PC phone. If pairing is unsuccessful, the steps above may be repeated.

c. ANSWERING/RECEIVING A CALL

When the phone is receiving a call, two dissimilar ring tones will be heard on the phone and on the Headset.



1. When answering is done on the Headset (*that is, pressing the multi-function button once*), the ongoing call can be heard from it.
2. When answering is done on the phone, ongoing call can be heard from the phone (*not on the Headset*). But if you wish to hear and transfer the call to the Headset, just press once on the Headset's multi-function button.
3. To terminate the call, press down the multi-function button once.

d. MAKING A CALL with the Headset on

Normal dialing

With your Pocket PC Phone, you can make a call using different methods. Please refer to your PC Phone's User Guide.


The most direct method is by using the Phone keypad.

1. Press  button to bring up the dialer screen.
2. Tap the number on the keypad, and then tap  key.

Note: Ongoing call will be heard on the phone and not immediately on the Headset. You have to press once on the Headset's multi-function button to transfer the sound to the Headset.

3. To terminate the call, press down the multifunction button once.

e. AUDIO TRANSFER

Audio Transfer can be done by pressing down the multi-function button once or accessing on the phone's Bluetooth Headset  icon.

f. **SETTING THE VOLUME**

The Headset has a digital volume control which can be accessed through the *multi-function button*. Volume setting can be done during calls only.

1. Switch the multi-function button sideways in a clockwise direction to increase the volume.
2. Switch it counterclockwise to decrease the volume.
3. Continuous sideward switching of the multi-function button (*clockwise or counterclockwise*) can rapidly increase or decrease the volume.

Note: If the volume set is too high, it can cause feedback (whistling sound), echo or background noise during calls on some cell phones.