

USING WITH SONY ERICSSON T68/T68i

a. ACTIVATING THE BLUETOOTH

You must activate the Bluetooth feature of your phone to establish a Bluetooth connection between your cell phone and other Bluetooth devices.

1. Go to Menu by pressing the joystick. Scroll to *Connect*, **YES**. Select *Bluetooth*, **YES**.
 Select *Options*, **YES**. *Operation mode*, **YES**. *On*, **YES**.
2. Continue pressing **NO** to exit.

QUICK ACCESS:

Press *Menu* followed by the sequence of numbers below.

	Connect	Blue tooth	Options	Operation mode
T68	8	3	-	2
T68i	8	4 (or 3 for T68i R7)	4	1

b. PAIRING TO THE CELLULAR PHONE (not possible while charging the Handsfree Kit)

Pairing will create a link or connection between your two Bluetooth devices, the Handsfree Kit and your phone.

1. Bring the cellular phone at about 20 cm from the Handsfree Kit.
2. Turn off the Handsfree Kit and wait for about 4 seconds.
3. While pressing the *Answer Button*, turn ON the Handsfree Kit by sliding the *Power Switch* to the right. Keep the Answer Button pressed for approximately 10 seconds until you hear a distinctive tone and the Bluetooth indicator LED changes from blinking blue to alternately blinking red and blue. The Handsfree Kit is now in pairing mode.
4. **For T68 and T68i older versions, R6 and below, shortly press the Answer Button again for a short time, to access headset pairing mode.**
5. Go to Menu by pressing the joystick. Scroll to *Connect*, **YES**. Select *Bluetooth*, **YES**.
6. Select *Paired devices*, **YES**. *Add device*, **YES**. Choose *Phone initiates*, **YES**. Choose *Headset/Handsfree*, **YES**. The phone will then search the device to be added. After the device is found, press **YES**.

QUICK ACCESS (for steps 5 and 6):

Press *Menu* then follow the sequence of numbers below:

	Connect	Blue tooth	Paired devices	Add device	Phone initiates	Headset/ Handsfree
T68	8	3	2	Yes	1	2
T68i	8	4 (or 3 for T68i R7)	2	Yes	1	2

7. Enter "0000" as the passkey. If the pairing is successful, the alternating red/blue lights will stop. Press **YES** to confirm the name of the device. If the pairing is unsuccessful, the steps above may be repeated.
8. Continue pressing **NO** to exit from menu.

The Handsfree Kit is paired and ready to use. An icon will appear during the standby mode indicating that the Handsfree Kit is linked with the phone.

c. ANSWERING/RECEIVING A CALL

When the phone is receiving a call, a ring tone will be heard on the Handsfree Kit.

1. Press once on the Answer Button to answer the call.

2. If you wish to answer the call on the cellular phone, press **YES** and the call will automatically be transferred to the phone. Pressing the Answer Button again will transfer the call to the kit.
3. To terminate the call, press the Hang-Up Button.

d. **MAKING A CALL with the Handsfree Kit on**



Normal dialing

1. Enter the contact number and press **YES**. Audio can be heard on the Handsfree Kit. Simultaneously, a question "*Retrieve call in phone?*" will be displayed. Ignoring or pressing "*No*" will retain the audio to the Handsfree Kit. Pressing "*Yes*" will transfer the audio to the phone.
2. Shortly press the Hang-Up Button to terminate the call.



Voice dialing

Refer to step h and i for the procedure when activating and recording for voice dialing.

1. Shortly press the Answer Button to activate the voice dialing.
2. A beep will then be heard on the Handsfree Kit prompting the user to say the name of the person to call.
3. Say the name. The name will be played back to you. The phone will then place the call automatically. In case the phone does not recognize the name spoken, the steps above may be repeated.
4. Shortly press the Hang-Up Button to terminate the call.



Redialing

For T68i R6 and R7, make a long press on the Answer Button. Audio will be heard on the Handsfree Kit.

e. **AUDIO TRANSFER**

Audio Transfer can be done by pressing the *Answer Button* or accessing the phone's *Menu* during ongoing calls.

f. **REJECTING A CALL**

For T68i R7, Shortly press the Hang-Up Button to reject an incoming call.

g. **SETTING THE VOLUME**

Setting the volume can be done using the Volume Control.

1. Turn it clockwise to increase the volume.
 2. Decrease the volume by turning it counter-clockwise.
- Note: If the volume is too high, it can cause feedback (whistling sound), echo or background noise during calls on some phones.*

h. **ACTIVATING THE VOICE DIALING**

Use your phone when recording for the voice dialing. Before voice dialing, you must first turn on the name dialing function and record your voice. To turn voice dialing on:



Using T68 Sony Ericsson

1. Go to Menu by pressing the joystick. Scroll to *Settings*, **YES**. *Voice control*, **YES**.
2. *Voice settings*, **YES**. *Voice dialing*, **YES**. Select *On*, **YES**.
3. Continue pressing **NO** to exit



Using T68i Sony Ericsson

1. Go to Menu by pressing the joystick. Scroll to *Settings*, **YES**. *Voice control*, **YES**. *Voice dialing*, **YES**.
2. Select *On*, **YES**.
3. Continue pressing **NO** to exit.

QUICK ACCESS:

Press *Menu* followed by the sequence of numbers below.

	Settings	Voice control	Voice settings	Voice dialing	On
T68	5	8	1	1	1
T68i	5	6	-	1	1

i. **RECORDING FOR VOICE DIALING**

Voice dialing entries must be stored in the phone's memory (not on the SIM card!).

**Using T68 Sony Ericsson**

1. Go to *Menu* by pressing the joystick. Scroll to *Settings* and press **YES**. Choose

Voice control, YES. Voice Commands, YES. Select a contact, YES. Add voice, YES.

2. Follow the instructions in the display. An icon will appear next to a contact name which has a voice command.
3. Continue pressing **NO** to exit.

**Using T68i Sony Ericsson**

1. Go to *Menu* by pressing the joystick. Scroll to *Settings* and press **YES**. Choose *Voice control, YES* then go to *Voice dialing, YES. Edit name, YES. Add voice, YES.*
2. Select a contact, **YES**.
3. Follow the instructions displayed. An icon will appear next to a contact name which has a voice command.
4. Continue pressing **NO** to exit.

QUICK ACCESS:

Press *Menu* followed by the sequence of numbers below.

	Settings	Voice control	Voice commands	Contacts
T68	5	8	2	4
	Settings	Voice control	Voice dialing	Edit names
T68i	5	6	1	2

Note: Record your voice command in a quiet place so that only your voice will be recorded on the phone.