

## USING WITH SAMSUNG SGH-E620

### ACTIVATING THE BLUETOOTH

You must activate the Bluetooth feature of your phone to be able to establish a Bluetooth connection between your phone and your SuperTooth II kit as well as with other Bluetooth devices.

1. Press **Menu > Settings > Bluetooth > Activation > On**.
2. Press **Back** as many times as needed to return to standby mode.

### PAIRING TO THE CELLULAR PHONE (Not possible while charging the SuperTooth II)

Pairing will create a link or connection between the two Bluetooth devices - the SuperTooth II kit and your phone.

1. This SuperTooth II kit supports either **Handsfree** or **Headset** pairing mode. First, refer to **Compatibility Table** for suggested pairing modes to be able to determine what pairing mode is best for your phone. **Handsfree** and **Headset** profile differs in pairing procedure. (*Note: In the Compatibility Table, you can find that Samsung SGH-E620 belongs to Handsfree Profile.*) Proceed with the instructions.
2. Bring the mobile phone at about 20cm from SuperTooth II.
3. The SuperTooth II is initially off. Turn it on by flipping up the **Swivel Arm(1)** to 55° position. The **Bluetooth Indicator(9)** will glow (*blue blink*).
4. Simultaneously press the **Reject Button(2)** and **Pick-Up/Hang-Up Button(7)** for about 10seconds. A distinctive tone will be heard and the Bluetooth Indicator LED will change from blinking blue to alternate blinking red and blue. SuperTooth II is now in **Handsfree Pairing Mode**.
5. While the kit is at pairing mode, access the Bluetooth menu of your phone. Press **Menu > Settings > Bluetooth > My devices > Search new device**. The phone will then search for pairable devices until it displays them in the list.
6. Highlight the name of this kit and press **Select**.
7. Enter PIN "0000" then press **Ok**. (Wait until "Paired with ..." and "Connected" will be shown briefly.)
8. Press **Back** as many times as needed to return to standby mode. Pairing is successful if the alternating red/blue lights of **Bluetooth Indicator(9)** will stop and then change to plain blinking blue. Normally, the phone would also show briefly on its display if it's already paired and connected to SuperTooth II or if pairing with it failed.

The SuperTooth II kit is now ready to use.

### AUTO ACCEPT MODE

When the SuperTooth II is turned off, its link with the phone is disconnected. This auto accept mode procedure is recommended to allow automatic reconnections (*between SuperTooth II and your phone*) the moment the kit is turned back on.

1. Press **Menu > Settings > Bluetooth > My devices**.
2. Under *My devices*, highlight *SuperTooth II* > press *Options > Authorise device*.
3. Press **Back** as many times as needed to return to standby mode.

### ANSWERING / ENDING A CALL

When you receive a call, ring tone will be heard simultaneously on SuperTooth II and on the phone or on the SuperTooth II only (*depending on your phone model*).

1. Just shortly press **Pick-Up/Hang-Up Button(7)** to answer the call.
2. When communication is over, press the **Pick-Up/Hang-Up Button(7)** to terminate the call.

### MAKING A CALL

#### Normal dialing

Enter the contact number and send. Normally, audio will be on the kit.

**Note: With some phones like Siemens S55; Panasonic X70, audio is always on the phone during an outgoing call. You will need to press Pick-Up/Hang-Up Button(7) to transfer the audio to your kit. (Also, refer to "Compatibility Table" for other helpful remarks.)**

### Voice/Name dialing

**Note: Voice dialing entries must be stored in the phone's memory (not on the SIM card!).**

1. **ACTIVATING VOICE/NAME DIALING: No need to record for a voice/name command.** This phone Samsung SGH-E620 can initiate voice/name dial not through the recorded voice but through the **name or words** you saved for each particular contact in your phonebook. **Any voice** will be accepted as long as it's speaking exactly the name/words entered or saved, the contact will be dialed. Before Name dialing, you must first turn on the *Name Dial* functions.
2. Press **Menu > Applications > Voice Commands > Settings > Voice Commands > Enable**.
3. Press **Back** as many times as needed to return to standby mode.
4. Activate Names Settings: (Names with check marks are available for Name dial.)  
Note: **No need to record for a voice command.** Go back to **Menu > Applications > Voice Commands > Settings > Activate names >** highlight the name or contact which you want to make a name dial > then press **Options> Mark** (to mark check on the box which corresponds to the name/ contact).
5. Press **Back** as many times as needed to return to standby mode.

Execute Voice/Name dialing on your kit by proceeding with the instructions.

6. Shortly press **Pick-Up/Hang-Up Button(7)**.
7. A voice instruction and a beep will then be heard on the SuperTooth II prompting the user to say the **Words/Name** saved for a contact to call.
8. Say the words/name. The phone will then place the call automatically.
9. When communication is over, press the **Pick-Up/Hang-Up Button(7)** to terminate the call.

### REDIALING (Handsfree profile only)

Make a long press on the **Pick-Up/Hang-Up Button(7)**. The phone would open the last dialed numbers. Choose which number to redial.

### AUDIO TRANSFER

#### Kit to Phone

Flip down the **Swivel Arm (1)** to 0° position (or turn-off the unit). This will automatically transfer the audio from the kit to the phone.

#### Phone to Kit

For Nokia Phones:

Flip up the **Swivel Arm** from 0° to 55° or 210° positions. (or turn-on the unit). This will automatically transfer the audio from phone to kit.

For Other Phone Models:

Flip the **Swivel Arm** up from 0° to 55° or 210° positions (or turn-on the unit).

Then press shortly the **Pick-Up/Hang-Up Button(7)**. The audio will be transferred from the phone to the kit.

### REJECTING A CALL (Handsfree Profile only)

Press **Reject Button(2)** to reject an incoming call.

### SETTING THE VOLUME

Set the volume using the **Volume Control(11)**.

1. Turn it clockwise to increase the volume.
2. Turn it counter clockwise to decrease.

*Note: If the volume set is too high, it can cause feedback (whistling sound), echo, or background noise during calls on some cell phones.*